




Tornador®

PH - 1 5



No.	Description	No.	Description	No.	Description
1	head cover / scalp shield	18	carbon brushes	35	shaft
2	screws	19	brush spring	36	clip
3	rubber bolt	20	speed adjuster	37	bearing
4	screws	21	screws	38	AL gear box (downside)
5	AL gear box (upper)	22	body handle (upper)	39	protector
6	small gear	23	body handle (downside)	40	rubber ring
7	bearing	24	screws	41	screw
8	block plate	25	switch	42	acentric wheel
9	rotor	26	screws	43	screw
10	magnet ring	27	cord block	44	bearing
11	bearing	28	cord gloove	45	counter weight
12	wind block ring	29	cord with plug	46	screw
13	screws	30	D-handle	47	acentric shaft
14	stator	31	bearing	48	backing plate
15	bearing cover	32	clip	49	screw
16	body	33	big gear		
17	carbon brush bracket	34	woodruff-key		